


# Rogue Luggage Carrier



| Item Number | Part Number | Description  | Quantity |
|-------------|-------------|--|----------|
| 1 - 8       | 504465      | Luggage Carrier Kit, Rogue/RG ALX/LW XP  | 1        |
| 1           | 003430      | Luggage Carrier Fork Assembly  | 2        |
| 2           | 003412      | Luggage Carrier Clamp 1.375<br><i>Used to mount Luggage Carrier to the frame</i>                   | 4        |
| 3           | 003413      | Luggage Carrier Barrel   | 2        |
| 4           | 100780      | M6 x 25 SHCS ZC<br><i>Only used when Luggage Carrier is mounted to the frame</i>                   | 2        |
| 5           | 100658      | M6 Nylock Nut Blk Zn   | 2        |
| 6           | 100667      | M6 x 12 BTN SHCS BLKZC w/Patch   | 4        |
| 7           | 003409      | Luggage Carrier Clamp .75<br><i>Used to mount Luggage Carrier to the footrest tubes/extensions</i> | 4        |

| Item Number | Part Number | Description  | Quantity |
|-------------|-------------|--|----------|
| 8           | 101845      | M6 x 22 SHCS Blk Zn<br><i>Only used when Luggage Carrier is mounted to the footrest tubes/extensions</i> | 2        |