


















<p>14" PLUSH</p> <p>P1400</p>	 <p>2-1/2"</p>	 <p>4"</p> <p>7-1/2"</p>	 <p>5"</p> <p>13-3/4"</p>	 <p>1-3/4"</p>	
<p>10" PLUSH</p> <p>P1000</p>	 <p>1-1/4"</p>	 <p>6"</p>	 <p>5"</p> <p>9-1/4"</p>	 <p>1-3/4"</p>	
<p>8" PLUSH</p> <p>P800</p>	 <p>1"</p>	 <p>5-1/2"</p>	 <p>5"</p> <p>7-1/2"</p>	 <p>1-3/4"</p>	
<p>Adjust-A-PLUSH</p> <p>Standard: P8088</p> <p>Narrow: P8044</p> <p>Medium: P8066</p>	 <p>Standard: 2" - 6" Narrow: 1.75" - 4" Medium: 2" - 5"</p>	<p>Standard Adjustment: 8" - 18"</p>  <p>5"</p>	<p>Narrow Adjustment: 6" - 14"</p>  <p>3"</p>	<p>Medium Adjustment: 7" - 16"</p>  <p>4"</p>	 <p>1-3/4"</p>