


(Discontinued) Catalyst Push and Pull to Lock Wheel Locks



Notice: Chair configuration review required prior to parts being quoted or ordered.

Item Number	Part Number	Description	Quantity
1a, 4b, 5	503206	Wheel Lock Assembly, Push Right w/ Instruction This kit contains 200251 wheel lock along with an instruction for reversing the wheel lock.	1
1b, 4b, 5	503205	Wheel Lock Assembly, Push Left w/ Instruction This kit contains 200252 wheel lock along with an instruction for reversing the wheel lock.	1
2a, 4b, 5	503207	Wheel Lock Assembly, Pull Right w/ Instruction	1

Item Number	Part Number	Description	Quantity
		This kit contains 200253 wheel lock along with an instruction for reversing the wheel lock.	
2b, 4b, 5	503208	Wheel Lock Assembly, Pull Left w/ Instruction	1
		This kit contains 200254 wheel lock along with an instruction for reversing the wheel lock.	
1a, 3, 4a, 5	503209	Wheel Lock Assembly, Push Extension Right w/ Instruction This kit contains 200410 wheel lock along with an instruction for reversing the wheel lock.	1
1b, 3, 4a, 5	503210	Wheel Lock Assembly, Push Extension Left w/ Instruction This kit contains 200411 wheel lock along with an instruction for reversing the wheel lock.	1
2a, 3, 4a, 5	503211	Wheel Lock Assembly, Pull Extension Right w/ Instruction This kit contains 200412 wheel lock along with an instruction for reversing the wheel lock.	1
2b, 3, 4a, 5	503212	Wheel Lock Assembly, Pull Extension Left w/ Instruction This kit contains 200413 wheel lock along with an instruction for reversing the wheel lock.	1
3	200369	Wheel Lock Extension	1
4a	102336	Wheel Lock Cover Plastic Used with Kits 503209 - 503212.	1
4b	111247	Wheel Lock Cover Plastic Used with Kits 503205 - 503208.	1
5	003415	Standard Wheel Lock Bar	1
6	001321	Wheel Lock Mount Bar Extended Used as needed	1