

ROHO Select Series Cushion Sizing Chart


For Cushions

ROHO Quadro Select Low Profile Cushion (QS)

ROHO Quadro Select Mid Profile Cushion (QS)

ROHO Quadro Select High Profile Cushion (QS)

ROHO Contour Select Cushion (CS)



Standard Cushions (QS/CS) "Fits Chair" Range - Inches									
Width (Inches)					Depth (Inches)				
				A	B			C	D
Measured Chair Range (narrowest to widest)	Number of Cells	Cushion Cell to Cell	Cushion Base			Measured Chair Range (narrowest to widest)	Number of Cells	Cushion Cell to Cell	Cushion Base
8.25	10	5	8.25	11	8.25	10	5	8.25	10
10	11.75	6	10	12.75	10	11.75	6	10	11.75
11.75	13.25	7	11.75	14.5	11.75	13.25	7	11.75	13.5
13.25	15	8	13.25	16	13.25	15	8	13.25	15.25
15	16.75	9	15	17.75	15	16.75	9	15	17
16.75	18.5	10	16.75	19.5	16.75	18.5	10	16.75	18.5
18.5	20.25	11	18.5	21.25	18.5	20.25	11	18.5	20.25
20.25	21.75	12	20.25	23	20.25	21.75	12	20.25	22
21.75	23.5	13	21.75	24.5	21.75	23.5	13	21.75	23.75
23.5	25.25	14	23.5	26.25	23.5	25.25	14	23.5	25.5

Select cushion cell height:

- High Profile 4.25 inches
- Mid Profile 3.25 inches
- Low Profile 2.25 inches
- Contour Select various cell heights