


Rogue / Rogue ALX / Little Wave XP Wheel Lock Clamps



Item Number	Part Number	Description	Quantity
1a, 2a, 5, 6	501001	Wheel Lock Clamp Assembly, Rigid, Standard <i>Used with Under Seat Scissor Lock, Short Thro Scissor Lock and Low Profile Scissor Lock,</i>	1
1b, 2b, 5, 6	501002	Wheel Lock Clamp Assembly, Rigid, Modified <i>Used with Push to Lock, Push to Lock (Flush Mount), Pull to Lock, Push to Lock w/ Extension Handle, Pull to Lock w/ Extension Handle and Grade Aids</i>	1
3-6	501003	Wheel Lock Clamp Assembly TI, RG ALX/LW XP	1
1a	000376	Clamp Top 1.375" Rigid <i>Used with Under Seat Scissor Lock, Short Thro Scissor Lock and Low Profile Scissor Lock</i>	1
1b	000461	Clamp Top 1.375" Modified Rigid <i>Used with Push to Lock, Push to Lock (Flush Mount), Pull to Lock, Push to Lock w/ Extension Handle, Pull to Lock w/ Extension Handle and Grade Aids</i>	1

Item Number	Part Number	Description	Quantity
2a	000377	Clamp Bottom 1.375" Rigid <i>Used with Under Seat Scissor Lock, Short Thro Scissor Lock and Low Profile Scissor Lock</i>	1
2b	000967	Clamp Bottom 1.375" Extended Rigid <i>Used with Push to Lock, Push to Lock (Flush Mount), Pull to Lock, Push to Lock w/ Extension Handle, Pull to Lock w/ Extension Handle and Grade Aids</i>	1
3	000378	Clamp Top 1.125"	1
4	000379	Clamp Bottom 1.125"	1
5	100780	M6 x 25 SHCS ZC	2
6	101835	M6 Lock Washer Blk Zn	2