


# (Discontinued) Catalyst Push and Pull to Lock Wheel Locks



Notice: Chair configuration review required prior to parts being quoted or ordered.

Item Number	Part Number	Description	Quantity
1a, 4, 5	503206	Wheel Lock Assembly, Push Right w/ Instruction <i>This kit contains 200251 wheel lock along with an instruction for reversing the wheel lock.</i>	1
1b, 4, 5	503205	Wheel Lock Assembly, Push Left w/ Instruction <i>This kit contains 200252 wheel lock along with an instruction for reversing the wheel lock.</i>	1
2a, 4, 5	503207	Wheel Lock Assembly, Pull Right w/ Instruction	1

Item Number	Part Number	Description	Quantity
		<i>This kit contains 200253 wheel lock along with an instruction for reversing the wheel lock.</i>	
2b, 4, 5	503208	Wheel Lock Assembly, Pull Left w/ Instruction <i>This kit contains 200254 wheel lock along with an instruction for reversing the wheel lock.</i>	1
1a, 3-5	503209	Wheel Lock Assembly, Push Extension Right w/ Instruction <i>This kit contains 200410 wheel lock along with an instruction for reversing the wheel lock.</i>	1
1b, 3-5	503210	Wheel Lock Assembly, Push Extension Left w/ Instruction <i>This kit contains 200411 wheel lock along with an instruction for reversing the wheel lock.</i>	1
2a, 3-5	503211	Wheel Lock Assembly, Pull Extension Right w/ Instruction <i>This kit contains 200412 wheel lock along with an instruction for reversing the wheel lock.</i>	1
2b, 3-5	503212	Wheel Lock Assembly, Pull Extension Left w/ Instruction <i>This kit contains 200413 wheel lock along with an instruction for reversing the wheel lock.</i>	1
3	200369	Wheel Lock Extension	1
4	102336	Wheel Lock Cover Plastic	1
5	003415	Standard Wheel Lock Bar	1
6	001321	Wheel Lock Mount Bar Extended <i>Used as needed</i>	1